3200506
5 x 3.5 Triple Swivel Frame

Insert Photos

1. Remove wood rail by sliding out from side of frame. See Illustration # 1.
2. Remove front and back glass panels together with face paper by sliding out from side of frame. See Illustration # 2.
3. Insert photo into desired position between the two glass panels and slide back into the wooden frame. Repeat for each frame.



Illustration # 1



Illustration # 2